

## #11 bakers and casseroles



11-01 Baker oval L=20,5cm



11-02 Baker H=4.5cm 11.5x20.5cm



11-03 Baker oval L=20,5cm



11-04 Round baker-pan H=5cm, i



11-05 Large oval baker H=7,5cm,  
L=36,5cmx28cm



11-06 Waved edge dish H=5cm,  
20x15cm



11-07 Round waved edge dish  
H=4,5cm,



11-08 Rectangular baker H=4,2cm,  
20,5x26cm



11-09 Round baker H=4cm,

## #11 bakers and casseroles



11-10 Large rectangular baker  
 H=5cm, 25x32cm



11-11 Rectangular dish baker  
 H=5,7cm 16,5x23,5cm



11-12 Large round baker H=5,5cm,



11-13 Rectangular baker H=6,8cm,  
 26x31,5cm




11-14 Rectangular baker H=7,8cm,  
 27x38cm



11-15 Rectangular baker H=4cm,  
 17,5x20cm



11-17 Muffin Baker 6 Cups H=3,5cm,  
 L=29cmx20cm



11-18 Waved edge dish H=5cm,  
 24x19cm



11-19 Oval baker H=4,6cm, 11x19cm

## #11 bakers and casseroles



11-20 Large oval baker H=7,5cm,  
28x36,5cm



11-21 Oval baker small H=4cm,  
11x16cm



11-25 Heart shape baker H=4,2cm,  
20,5x21cm



11-26 Heart shape hanging baker  
H=4,2cm, 20,5x21cm



11-28 Small Rectangular Baker  
H=4,5cm, 15x22cm